



Assembly Instructions

Parts and Tools list


| NO | Name | Qty | NO. | Name | Qty |
|----|-----------------|------|-----|----------------|-----|
| 1 | Lifting System | 1set | 11 | Plastic Pad | 6 |
| 2 | Feet | 2 | 12 | Plastic Nut | 2 |
| 3 | M8*16 Screw | 8 | 13 | ST3.5*19 Screw | 2 |
| 4 | Bracket | 2 | 14 | ST4.8*19 Screw | 2 |
| 5 | M6*10 Screw | 8 | 15 | ST4.8*25 Screw | 6 |
| 6 | Support Beam | 1 | | | |
| 7 | 4mm Hex Spanner | 1 | | | |
| 8 | 5mm Hex Spanner | 1 | | | |
| 9 | M6*12 Screw | 12 | | | |
| 10 | Rubber Cushion | 6 | | | |




1 Loosen the 4 screws of beam using 4mm hex spanner, adjust the beam to proper position to fit the desktop




2 Attach legs to the beam using 8 of M6*12 screws




3 Attach feet to the legs using 8 of M8*16 screws.



4 Overturn frame and attach brackets to beam using 4 of M6*12 screws, and then fit the rubber cushions and plastic pad to the brackets and beams



5 Fix table top to frames with 6 of ST4.8*25 screws, then fix control boxes to below table top with 2 of ST4.8*19 screws, at last fix handsets to below table top with 2 of ST3.5*19 screws.



6 Connect the control box to the handset and to the motor

